
Navigating the Control

Seven (7) Main Screens




Input Screen

Everything necessary to setup, edit, and execute the active program.


These keys are for UltiMax users to feel comfortable inside WinMax.

Used for program and file manipulation.




Program Manager

- Program Manager Window: there are many visual references available in the program manager window
- Snapshot: image is stored with the program.
- **Description**: text can be entered into the description box.




Program Review Screen

- Data Blocks: a display of the current blocks that make up the program.
- Sub Blocks: the lines & arcs type of data used in each individual program block (if applicable).
- Tool Data: the tool used in a particular block in the program.
- Notes: tab available for the operator to add notes for setup, etc...




Tool Review Screen

- Works Like a Setup Sheet
 - Tool numbers and description displayed.
 - Highlighted tools display blocks used in program.
 - Uncheck box to see all tools in library.




Auxiliary Screen

- Auxiliary Functions:
 - used to access special screens.
 - quick access buttons for setup and programming screens.



Manual Screen

- Tool Management:
 - used for toolchanges and ATC map manipulation.
- Manual Function Setup:
 - access to manual functions such as: spindle speed, manual rapid feed, manual rapid move.
- Other Manual Functions:
 - Park Machine; ATC & Machine Diagnostics; Machine Warm-up; and machine Calibration.



Help Screen

- Content Sensitive:
 - should pop-up with current task related information.
- Searchable:
 - using the index tab, search the help data by entering content relevant information.
- Clickable Links:
 - all text links can be clicked to direct the user to more content relative information.